


# MICROFRIDGE DEFROST AND CLEANING INSTRUCTIONS

Avoid a **\$15** fine by following these steps.



- 1** Remove everything from inside your fridge and freezer.
- 2** Unplug the microfridge unit.
- 3** Lay a towel or newspaper in the interior bottom of the fridge and freezer. Ensure the towel extends outside the front of the fridge to catch any dripping water.
- 4** Allow the fridge and freezer to defrost for at least 12 hours with the doors open.
- 5** Clean and wipe down the fridge, freezer, microwave, as well as shelves and racks using warm, soapy water. Remove any soap using a damp cloth and wipe again with a dry cloth.
- 6** Allow the unit to dry completely with the doors open.